



6010.26 & 6010.26/HP

Remote Mounted Adjustable Pressure Regulators


606253		606255	
KIT 552		KIT 554	
Optional ▲		■	
CODE	Q.TY	CODE	Q.TY
090326	1	090326	1
110104	1	110104	1
110112	2	110106	2
110141	1	110112	2
120419	1	110141	1
150123	1	150123	1
181001	1	870104	1



Outlet



6010.26/HP	Maximum Flow	27.0 GPM / 102 lpm
	Maximum Pressure	560 PSI / 38 bar
6010.26	Maximum Flow	27.0 GPM / 102 lpm
	Maximum Pressure	350 PSI / 24 bar
	Inlet Port - Hose Barb	3/4" HB
	Outlet Ports - Hose Barb, Valve	(2) 1/2" HB
	Bypass - Hose Barb	3/4" HB



Revised 6-3-2024

Part #	Description	Qty	Part #	Description	Qty
0202.25	BYPASS HOSE BARB - STRAIGHT (OPTIONAL)	1	1203.41	BODY	1
0204.40	VALVE BODY	1	1204.19	STEEL POPPET - OPTIONAL ▲	1
0204.48	MAIN BODY	1	1403.06	WASHER	1
0205.10	VALVE CYLINDER	1	1403.07	WASHER	4
0205.11	VALVE CYLINDER CAM	2	1501.23	SEAT ▲■	1
0254.04	BYPASS HOSE BARB - ELBOW	1	1530.09	MOUNTING PLATE	1
0303.02	NUT	2	1603.22	PLUG	1
0604.09	DISCHARGE BARB NUT	2	1603.44	PLUG	2
0604.26	BYPASS BARB NUT	1	1801.17	ADJUSTMENT KNOB	1
0604.29	BARB NUT	1	1804.74	BOLT	4
0605.34	GASKET	2	1808.10	BOLT	2
0608.26	1/2" HOSE BARB W/GASKET	2	6062.88	REGULATOR CAM KIT	2
0608.46	BALL VALVE; LEFT	2	1810.01	STAINLESS STEEL BOLT - OPTIONAL ▲	1
0901.24	HIGH PRESSURE SPRING "6010.26/HP"	1	8701.04	URETHANE POPPET ASSEMBLY ■	1
0901.47	LOW PRESSURE SPRING "6010.26"	1	GG1000	PRESSURE GAUGE - 1000 PSI "6010.26/HP"	1
0902.25	DUMP VALVE LEVER	1	GG350	PRESSURE GAUGE - 350 PSI "6010.26"	1
0903.26	DIAPHRAGM ▲■	1	6062.53	REPAIR KIT - STEEL POPPET (KIT 552) OPTIONAL	1
1101.04	O-RING ▲■	1	6062.55	REPAIR KIT (KIT 554)	1
1101.06	O-RING ■	2			
1101.12	O-RING ▲■	2			
1101.41	O-RING ▲■	1			

▲ Parts Included in Repair Kit 6062.53 (KIT 552)
 ■ Parts Included in Repair Kit 6062.55 (KIT 554)

- Before operating or re-operating the pump, push the manual dump valve lever (0902.25) down, so the pump will start at zero pressure. FAILURE TO DO SO WILL VOID PUMP WARRANTY.
- Turn pressure adjustment knob (1801.17) counterclockwise to relieve spring tension. NOTE: Step 2 applies only to initial start-up, and is not necessary in daily operation of pump.
- Start unit and let run until air is evacuated from system, when only liquid is expelled from the bypass line.
- Return dump valve lever to the UP position. Open spray gun or spray boom and turn the pressure adjustment knob (1801.17) clockwise until desired operating pressure is achieved.